

STRAWBERRY JAM PECTIN

with powdered pectin

5½ cups crushed strawberries (about 3 quart boxes strawberries)
 1 package powdered pectin
 8 cups sugar

Yield: About 9 or 10 half-pint jars

Please read [Using Boiling Water Canners](#) before beginning. If this is your first time canning, it is recommended that you read [Principles of Home Canning](#).

Procedure: [Sterilize canning jars](#) and prepare two-piece canning lids according to manufacturer's directions.

To prepare fruit. Sort and wash fully ripe strawberries; remove stems and caps. Crush berries.

To make jam. Measure crushed strawberries into a kettle. Add pectin and stir well. Place on high heat and, stirring constantly, bring quickly to a full boil with bubbles over the entire surface. Add sugar, continue stirring, and heat again to a full bubbling boil. Boil hard for 1 minute, stirring constantly. Remove from heat; skim.

Fill hot jam immediately into hot, sterile jars, leaving ¼ inch headspace. Wipe rims of jars with a dampened clean paper towel; adjust two-piece metal canning lids. Process in a **Boiling Water Canner**.

Table 1. Recommended process time for **Strawberry Jam** in a boiling water canner.

		Process Time at Elevations of		
Style of Pack	Jar Size	0 - 1,000 ft	1,001 - 6,000 ft	Above 6,000 ft
Hot	Half-pints or Pints	5 min	10	15

This document was adapted from "How to Make Jellies, Jams and Preserves at Home." Home and Garden Bulletin No. 56. Extension Service, United States Department of Agriculture. 1982 reprint. National Center for Home Food Preservation, June 2005.